

Attaching the Arena grab ring and which fitting to use.

Does your bed mechanism sit inside the bed surround? Picture A (for hook)

or is it level with the bed surround Picture B (for shimmy)?


If it is level then the shimmy should be used but if the mechanism sits inside as in picture A below then it is the hook.

Two types of fittings

A is used when the frame sits inside the bed surround as below




A is hook and B is Shimmy




B Correct Fitting



B is used when the frame sits level or just below the bed surround **(most common type)**



Moving part of Slatted Bed Frame Bed surround



Non moving part Slatted bed frame

Incorrectly Fitted as gap between bed surround and rail.

